



# Human Vision System

- Cones – colour
- Rods – intensity
- High intensity range –  $10^{10}$ , achieved by sensitivity adaption
- Logarithmic sensitivity to light



**FIGURE 2.2**  
Distribution of rods and cones in the retina.



*Image credit: Digital Image Processing 2<sup>nd</sup> Edition, Rafael Gonzalez and Richard Woods, Prentice Hall, 2002, Chapter 2, (page 35, figure of cross section from human eye from), (page 37, distribution of rods and cones in the retina)*

# Distributing Intensity Levels


- Logarithmic sensitivity – e.g. perceived brightness increase of 20w-22w is same as 100w-110w
- Ratio important (in above example  $r=1.1$ )
- To display  $n+1$  intensity levels ( $I_0-I_n$ ) we should have:  $I_1/I_0=I_2/I_1=\dots=I_n/I_{n-1}=r$  (the ratios,  $r$ , of each successive intensity are equal)
- Therefore,  $I_k=r^k I_0$  and since  $I_n=1.0$ ,  $r=(1.0/I_0)^{1/n}$

# Distributing Intensity Levels

- e.g. (from book)
- For 3 levels, and  $I_0=1/8$ ,  $r=2$
- $I_1=rI_0=1/4$
- $I_2=r^2I_0=1/2$
- $I_3=1.0$


# Gamma Correction

- Monitor response curve:
- $I = aV^\gamma$
- e.g. PAL specification has gamma=2.8
- RGB=(64, 64, 64) should be half the intensity of (128, 128, 128), but under PAL is not.
- Need gamma correction





# Gamma Correction Equation

- $V = (I/a)^{1/\gamma}$  (assume  $a=1$  for this course)
- Implementation: divide pixel by 255 (get  $I$ , a number between 0 and 1)
  - Find  $\text{power}(I, 1.0/\text{gamma})$
  - Multiply by 255 to get new intensity
  - (Do for each colour channel, for each pixel)



# Example



- Input: Grey Scale
- Monitor displays
- This matches gamma=2.8, so correct with gamma=2.8 (i.e.  $I=V^{1/2.8}$ )

# Further Reading

- [https://en.wikipedia.org/wiki/Gamma\\_correction](https://en.wikipedia.org/wiki/Gamma_correction)